



MODULAR CABLE TESTER

Model 72-6269 is used for testing modular cable RJ-45 pin continuity and cross wiring. Also tests cables that are reverse wired or wired straight-thru. (Up to eight conductors.) (See Fig. 1)




Test Operation:

- Step 1. Make sure all of the dials are in the "on" position.
- Step 2. Connect the cable both ends to the sockets of tester. (See Fig. 2)



- Step 3. After the tested cable is connected, the LEDs will be illuminated as follows: (See Fig. 3)



If the cable is a wired straight-thru, the LEDs will illuminate green. If it is reverse wired, the LEDs will illuminate red.

Pin Configuration Test:

If the cables are not correctly wired, use the jumper wires provided, to jump between pin sockets to check pin configuration.